Guitar Amp Replica Clock

Installation

- 1. Install a FRESH AA Battery (but not a rechargeable type). NOTE: The movement may have an "ON/OFF" switch on the back of the unit. This switch must be in the "ON" position for the unit to run.
- 2. Set correct time of day using the dial on the clock movement to set the hands. Hands may also be set by moving the minute hand with your fingers. Move the minute hand only in a "CLOCKWISE" direction.
- 3. Find a wall stud from which to hang your clock. Mark the spot where you are going to drill with a pencil. Place a screw against the spot you marked; depending on the thickness of your wall a 1-1/2" to 2 inch screw should work. Drill into the spot you marked. The screw should stick out a 1/2 inch or so. Slip the clock's hang hole over the head of the screw. If need be, straighten the clock so that it hangs evenly.



Designed and Made in the USA by Droplight Industries, LLC www.droplightind.com